

# Lab 4

## Projectile Motion

### Overview

The goal of this lab is very simple: predict the motion of a launched projectile in order to knock down some Jenga blocks.

Quantitatively, this means predicting  $\Delta x$  based on the angle of the launcher  $\theta$  and the initial velocity  $v_i = |\vec{v}_i|$ . Theoretically, you can find  $\Delta x$  using equation 3 below. Experimentally, you can use the taped down carbon paper to mark where the ball hit and measure  $\Delta x$  using a meterstick.

### Theory

In order to make your predictions, you should assume that the launched projectile is subject only to the constant gravitational force  $\vec{F}_g = \langle 0, -mg, 0 \rangle$ , where  $g = 9.8 \text{ m}\cdot\text{s}^{-2}$ .

$$v_x(t) = v_{x,i} + \frac{F_x}{m}t \quad (1)$$

$$v_y(t) = v_{y,i} + \frac{F_y}{m}t \quad (2)$$

$$x(t) = x_i + v_i \cos(\theta)t + \frac{1}{2} \frac{F_x}{m}t^2 \quad (3)$$

$$y(t) = y_i + v_i \sin(\theta)t + \frac{1}{2} \frac{F_y}{m}t^2 \quad (4)$$

The time of flight  $\tau$  is given by setting equation 4 equal to zero and solving for  $t$ . This results in a quadratic equation, the roots of which are given by:

$$\tau = \frac{v_i \sin \theta + \sqrt{v_i^2 \sin^2 \theta - 2 \frac{F_y}{m} y_i}}{g} \quad (5)$$

### Setup

This lab uses a metal ball of unknown mass and a projectile launcher. The launcher has three settings (slow, medium, and fast) as indicated by the number of clicks you hear when pushing the ball down the barrel. **Do not use the fast setting!** The only measured quantities will be the horizontal distance  $\Delta x$  from the launcher to the landing point of the projectile, the launch angle of the projectile launcher, and the vertical distance  $\Delta y$  from the ground to the barrel of the launcher. The time of flight is difficult to measure, so we will use equation 5 to “measure” the time of flight. To measure the initial velocity, consider setting the projectile launcher at a very special angle.

Note that if you miss, the ball will roll through the blocks without knocking them down. You can use the stools around the lab as a backboard.

You can use the meterstick to mark where the initial  $x$  position ( $x_i$ ) is on the carpet below the projectile launcher. Do not measure from the end of the barrel! Instead, measure from the crosshairs on the barrel.

**You should knock over the blocks two separate times, varying either  $v_0$  or  $\theta$  or both.**